

D426 with modern Snarewires Part 1 and Part 2

Part 1 modify the old strainer



For this snare no new wires are available



Use a longer wire for Freefloating or other snares



and build yourself an adapter(not me!!) like this



and you can use the snare like in the early days

SONOR D426

Part 2 new strainer on old snare



turn the snare like the picture



loose the strainer screws



better picture!!



remove wire



then push out the metal
piece here!



remove the part (on
every side of the snare)

you see the metalpart
on the left.



then it looks like that.



after removing this part
you can put on a 555
strainer on the old holes.



no new holes needed



also a butt end fits



on the old holes



sounds Great!!



looks not to good